

Llave Selectora de Combustible / Fuel Selector Switch



Características Generales / General Features

Llave Inyección

Permite la selección del tipo de combustible (Gasolina o GNC / GLP) en forma manual y el cambio se realiza automáticamente. El arranque se realiza normalmente a nafta, pasando a gas con una leve aceleración, en caso de emergencia puede arrancarse directamente a gas, incluye un sistema de detección de motor parado, que en caso de una parada de motor accidental, corta inmediatamente la salida de gas, evitando cualquier riesgo. Da indicación del nivel de gas en el tanque a través de 5 indicadores luminosos.

Injection Switch

It allows to select the kind of fuel (gasoline or CNG / LPG) manually and the change is done automatically. The engine is usually started on gasoline, passing over to gas with a light acceleration, in case of emergency it may be started directly on gas. It includes a detection system of engine stall, which in the case of an accidental stall of the engine immediately cuts off the gas supply, thus avoiding any risk. Through 5 light signals it indicates the tank's CNG / LPG level.

Llave Carburada

Permite la selección del tipo de combustible (Gasolina o GNC / GLP) y el cambio en forma manual. Durante la fase de arranque habilita la salida de gas para permitir un arranque rápido y eficiente. Cuando se realiza el pasaje de GNC / GLP a gasolina permite la superposición de ambos combustibles para evitar detenciones inesperadas del motor. Posee además un sistema de detección de motor parado, que en caso de una parada de motor accidental, corta inmediatamente la salida de gas, evitando cualquier riesgo. Da indicación del nivel de gas en el tanque a través de 5 indicadores luminosos.

Carburetor Switch

Allows to select the kind of fuel (gasoline or CNG / LPG) and the manual change. During the starting stage, it enables the gas outlet to allow a quick and efficient start. When the passage from CNG / LPG to gasoline is done, it allows both fuels to overlap so as to avoid unexpected engine stalls. It furthermore has a detection system of the stopped engine, which in the case of an accidental stall of the engine immediately cuts off the gas supply, thus avoiding any risk. Through 5 light signals it indicates the tank's CNG / LPG level.

Llave Selectora de Combustible / Fuel Selector Switch

Llave Inyección / Injection Switch

Código / Code	Componentes / Components
3046151	Módulo control llave inyección micro / Injection switch control module
3046106	Manómetro MGN2 con cable incorporado / Manometer MGN2 with wire
2196027	Mazo cable llave 5L 7x1 / 5L 7x1 switch wire harness

Llave Carburada / Carburetor Switch

Código / Code	Componentes / Components
3046044	Módulo control llave carburada TA 7x1 / TA 7x1 carburetor switch control module
3046106	Manómetro MGN2 con cable incorporado / Manometer MGN2 with wire
2196027	Mazo cable llave 5L 7x1 / 5L 7x1 switch wire harness

Certificaciones / Certifications

ISO 15500
NAG 415/417

Diagrama de Conexión / Connection Diagram

